
# Installation Instruction



#### UNPACKING INSTRUCTIONS


- Carefully open the carton, remove contents and lay out on cardboard or other protective surface to avoid damage.
- Check package contents against the Supplied Parts List in the next page to assure that all components were received undamaged. Do not use damaged or defective parts.
- Carefully read all instructions before attempting installation.

#### IMPORTANT SAFETY INFORMATION

- Install and operate this device with care. Please read this instruction before installation, and carefully follow all instructions contained herein. Use proper safety equipment during installation.
- Please call a qualified installation contractor for help if you don't understand these directions or have any doubts about the safety of the installation.

Do not use this product for any purpose or in any configuration not explicitly specified in this instruction. We hereby disclaims any and all liability for injury or damage arising from incorrect assembly, incorrect mounting, or incorrect use of this product.

#### **Supplied Parts List**



(1) 35mm Tube Support-a



(1) Disconnected "C" Clamp-b




(2) VESA Plate with Gas Spring Arm-c



(1)Stopper Ring-d



(2)M10x15 Bolt-e



(1)Allen Key-f



(8)M4x12 Thumb Bolt-g



(8)M4x30 Bolt-h



(8)M4 Space-i



(2)Axis Cover-j



(2)M6x12 Bolt-k



(1)Arm Connector-I



(2)Wire Clip-m

### **Tools Required**

### Phillips Screwdriver




## **CAUTION!**


This monitor desktop mount must be securely attached to the horizontal desk. If the mount is not properly installed it may fall, resulting in possible injury and/or damage.

### Step 1

### Install the "C" Clamp According to the Desktop Thickness





# Step 2 Install Stopper Ring to the Tube Support




### Step 3

### Assemble Arms and Install Arms to the Tube Support









### Step 4

### Mount the Monitor to VESA Plate









For Curved Back Monitor


# Step 5

### Make Necessary Adjustments, and Run Cables





### Adjust the Torque of Gas Spring



Adjust the torque of gas spring according to the weight of your monitor. If your monitor can not stay in the lower position, turn the grub screw clockwise(-). If your monitor can not stay in the higher position, turn the grub screw counterclockwise(+). Keep turning until monitor position can be raised and lowered easily.